

Product Tekloom® - High Performance Fused Textile
Content Polyester 85%-88%, Graffiti-Free® Tekloom® TPE 12-15%

General Maintenance

While Tekloom® is inherently stain resistant, it is important to keep it clean at all times to maintain the original look and feel. Spot cleaning with a clean, soft towel with clean water will remove most of the everyday stains.

Cleaning Code: W/S, Bleach [10:1], Dry Care™

Disinfection

This product can be disinfected with a 10:1 bleach dilution of water/bleach. Apply the solution using a misting spray bottle and gently scrub the affected area with a sponge or soft bristle brush. Allow the mixture to linger for the time specified by the Center for Disease Control and Prevention.

Avoid soaking the seamed area to prevent the bleach from penetrating thru the protective layer.

Rinse all cleaning agents thoroughly with water and wipe with a soft cloth

Residue left by cleaning agents will degrade and shorten the life and/or affect the product's appearance if not removed.

Approved Healthcare Cleaners

This list represents some of the most common options available and is not intended to be comprehensive.

3M C Diff Solution Tablets
3M Neutral Quat Disinfectant Cleaner Concentrate 23H
3M Neutral Quat Disinfectant Cleaner Concentrate 23L
3M HB Quat Disinfectant 25L
Amphyl
CariCide
CaviWipes XL
Clorox Healthcare Hydrogen Peroxide Cleaner Disinfectant Wipes
Ecolab A456 II
Ecolab Neutral Disinfectant Cleaner
Formula 409
Hydrogen Peroxide
Lysol Disinfectant Spray
Oxivir 1
Oxivir 5 16
Oxivir Plus
Oxivir Tb Wipes
Oxycide
Perisept
Sani-Cloth AF3 Germicidal Disposable Wipes
Steris [Coverage Spray HB Plus]
Stride Fragrance Free SC Neutral Cleaner
Virex 256
Vlrex Plus
Wexcide 128

**Tekloom® protects the woven fabric with a patented, clear TPE layer. All approved cleaning chemicals should stay on the surface. Avoid soaking the seamed area to prevent the cleaning chemicals from entering the base fabric or the foam underneath.*

**The cleaning recommendations above are just a guide and intended to help the maintenance of the specified product. Pointe neither guarantees, nor will take any responsibility the specific results, as testing of these products was conducted under laboratory conditions and results may vary under actual conditions.*

**Pointe is not liable for any intentional stains, and the damage resulting from lack of cleaning, the misuse of the cleaning agents, or the use of inappropriate cleaning agents for the product. Under no circumstance, shall Pointe be liable for any incidental, consequential, or other damage resulting from negligence, misuse, mishandling or exposure to any of the chemicals used in conjunction with the cleaning/maintenance of the product.*